SET UP


4 SCREEN CLASSIC






Take out the graphic panel, foot and supporting rod from the bag.

Unfold the 3-part supporting rod. Make sure that the parts click in each other. $\,$



Attach the stabilizing foot to the lower panel profile.



Take hold of the graphic panel and roll up. Place the supporting rod into circle cap on the stabilizing foot.



Attach the top profile to the top fastener of the supporting rod.



Place the system at the desired location and verify that the system is stable.

ACCESSORIES



Options include a lightweight and convenient low voltage spotlight in an attractive design.



Attach the spotlight on the top profile.